

The BigEasy™

Lockout Tool Kit *INSTRUCTIONS*

The Big Easy Tool

1A - (*Plastic Wedge*) - Insert the plastic wedge at the uppermost rear corner of the front door frame. Each vehicle will be a little different but start the wedge into the door gap and use the wedge to pry out the door frame enough to see where the weatherstrip contacts the body. Tapping the wedge with the heel of the hand, carefully guide the wedge between the weatherstrip and body. Continue inserting the wedge until there is enough gap to easily insert the BigEasy Tool.

1B - (*Optional Inflatable Easy Wedge*) - **LUBRICATE THE EASY WEDGE WITH WINDEX OR MILD DETERGENT.** Insert the Inflatable Easy Wedge at the uppermost rear corner of the door frame. The Easy Wedge should be inserted 2/3rds into the car. If obstructed by weatherstrip a plastic or wood wedge may assist. With experience the Easy Wedge will enter most cars without assistance. Inflate the wedge to allow insertion of the BigEasy.

2- Insert the BigEasy Tool into the vehicle interior and use the tip of the Tool to *manipulate the electric lock button, the sliding lock button, or the door opening handle.* If the bend in the BigEasy Tool is not sufficient, remove the Tool and adjust the bend to the required configuration for the vehicle at hand.

Note: The BigEasy Tool can often be used to tilt the inside rearview mirror to view a lock slide or door handle not directly visible from the working position.



◀ Paint Protector reduces friction between the car door and the BigEasy so the powder coating on the BigEasy does not rub off.

SureGrip Lock Knob Lifter

1- Insert the plastic wedge or optional Inflatable Easy Wedge into the uppermost rear corner of the front door frame just enough to relieve the pressure between the weatherstrip and body.

2- Insert the SureGrip strip into the interior of the vehicle and slide it down to the vertical lock knob. Hold one leg of the SureGrip strip with each hand. Push and pull opposite legs to "steer" the SureGrip as you lower it onto the vertical lock knob.

3- After the SureGrip strip is positioned on the vertical lock knob, pull rearward until snug to grip the knob and then add a slight upward pull to lift the vertical lock knob.

